

## Verona

## Adjustment instructions



## Seat height adjustment

Whilst seated locate the adjustment lever underneath the seat (rear RHS). Lift the paddle (twist lever clockwise) and the seat will lower. To raise the chair, lift the same paddle whilst taking your weight off the seat.



## Synchro mechanism tension adjustment

Whilst seated locate the large adjustment dial underneath the seat (front centre). Twist clockwise to increase the resistance of the tilt mechanism or anticlockwise to reduce resistance. Adjust the chair to be in equilibrium to your own body weight.



## Backrest angle lock adjustment

Whilst seated locate the adjustment lever underneath the seat (rear RHS). Pull the lever out to enable the backrest to recline. Push the lever in to lock the backrest in one of three locking positions.



## Lumbar support adjustment

Locate the lumbar support in the centre of the backrest frame. Slide the support up or down to the desired position.

## Optional adjustments



## Armrest position adjustment

All armrests have a button on the outside. Depress this to raise or lower the arms to suit. There are nine positions to choose from. With multifunction armrests you can move the armrest pad forward/backward, left/right or rotate slightly to suit you.



## Seat depth adjustment

Whilst seated locate the lever underneath the seat (front RHS). Lift the lever to release the seat and slide it to your desired position. There are six positions to choose from. The sprung mechanism will automatically return the seat back to min. depth when the lever is raised with no weight on the seat.