


# Libero Monitor Arm

Installation and Adjustment Guide.

## 1. Screen drooping?

Tightening the top joint is done by adjusting the grub screws hidden underneath.



Need more tension?

## Remove the cap.

If you need any more tensioning for a particularly heavy monitor or dual screens, you may also need to take off the removable plastic cap from the side and tighten this bolt (clockwise).



# Libero Monitor Arm

## Installation and Adjustment Guide.



Adjust here.



Do NOT adjust here.

If more tension is required, use the provided hex key to turn the screw anti-clockwise.



Add 3-4 turns at a time until the weight is balanced well.



## 2. Screen sinking?

## 3. Hide the cables!

Once the monitor is easy to move up, down and tilt forward and back, always remember to neatly stow away the cables using the removable bottom section plate. This helps the whole arm move and function smoother and for longer.

